

PerfectPaint Quick Start Application Guide

Overview: How to apply PerfectPaint over clean and sound substrates

Surface Preparation: Dissolve one half packet (4 oz) of PerfectCleaner into 3-5 gallons of warm water. Apply the PerfectCleaner using a stiff broom, mop, or deck brush. Once applied, rinse/mop the suds and dirt well with clean water. When the floor is dry to the touch, apply the PerfectPaint.

When apply PerfectPaint over existing tile or sheet vinyl: Use a wax stripper, wash surface, then apply PerfectPaint.

To repair damaged areas and low Spots Prep: Use PerfectPrimer to spot prime substrate in areas to be patched. Once primer is cured, fill low spots with your choice of polymer modified cement patching materials. Small cracks or holes can be filled with acrylic caulk.

Paint Application: Once all prep has been completed, use a brush or **3/8" nap roller** to apply first coat. After 12 hours, apply your second coat.

Coverage: for the two gallon pail for both coats: 400- 450 sq. ft.

Specifications: Apply PerfectPaint evenly by rolling it on as thickly as you can, and then back-rolling so it does not puddle. Professionals: If you are spraying a large area, use piston powered paint sprayer with a .27-.32 tip.

After 24 hours you can walk on the floor, or install a floating wood floor, carpet, or sheet vinyl system

NOTE: *When installing a new paint, epoxy, tile mastic or decorative cements, use PerfectPrimer*

Allow for 24 hour cure before applying concrete and 48 hours before applying epoxy type coatings.

When applying PerfectPaint over existing epoxy, acrylic sealers or other resinous floors: Remove loose and poorly adhered material. Lightly surface using a #100 Grit screen. Vacuum or sweep off grinding dust. Wipe down surface with acetone, or denatured alcohol, and then apply two thin coats of PerfectPaint.

Note: Work Clean! Wear socks or booties to avoid tracking dirt onto the painted surface. Dirt and dust are bond-breakers.